



# INSTALLATION GUIDE

**LOWDECK PLUS**



# LOWDECK PLUS

## 4 Applying the levelling compound

Upon completion of the panel installation, it's time to apply the self-levelling compound. Dependant on the floor covering, the compound should be laid at a minimum of thickness of 5mm for tiled floors or 9mm for vinyl.

## 5 Next steps...

Once the installation of the LowDeck Plus underfloor heating system has been completed, prior to laying your chosen floor covering, it's time to connect the pipework to the Minifold. See the Minifold installation guide for more information on these install steps.

